ORIFLAMME®

TABLES

Getting Started Guide

Assembly Instructions

User Guide

Table Top Maintenance

Warranty Information

DESIGNING FIRE

MANUFACTURER OF THE ORIFLAMME TABLE

(800) 445-4559 | www.designingfire.com

Fax: 651-305-6347 | info@designingfire.com

#253915-2528907

Installers: Please leave the instruction manual with the consumer for future reference.

©2013 Designing Fire, Inc. All rights reserved.

⚠WARNING

CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which has no odor.

Using it in an enclosed space can kill you.

Never use this appliance in an enclosed space such as a camper, tent, car or home.

⚠WARNING

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN AN EXPLOSION OR FIRE THAT MAY CAUSE PROPERTY DAMAGE, SERIOUS INJURY OR DEATH.

- **Children and adults should be alerted to the hazards of high surface temperature and should stay away to avoid burns or clothing ignition.**
- **Young children should be carefully supervised when they are in the area of the Oriflamme Fire Table.**
- **Clothing or other flammable materials should not be hung from the appliance, or placed on or near the Oriflamme Fire Table.**
- **Any guard or other protective device removed for servicing the appliance must be replaced prior to operating the Oriflamme Fire Table.**
- **Installation and repair should be done by a qualified service person. The Oriflamme Fire Table should be inspected before use and at least annually by a qualified service person. More frequent cleaning may be required as necessary. It is imperative that the control compartment, burners and circulating air passageways of the Oriflamme Fire Table be kept clean.**

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and instructions thoroughly before installing or servicing this equipment.

⚠ DANGER

If you smell gas:
1. Shut off the gas to the appliance.
2. Extinguish any open flame.
3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

⚠ WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

⚠ WARNING

FOR OUTDOOR USE ONLY.

PROPANE Installation

- Read the instructions provided thoroughly before installing and operating your Oriflamme Fire Table.
- Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury, and or death.
- CODE AND SUPPLY REQUIREMENTS: The Oriflamme Fire Table must be installed in accordance with local codes and ordinances, or in the absence of local codes, with the National Fuel Gas Code , ANSI Z223.1/NFPA 54 or the International Fuel Gas Code.
- The maximum inlet gas supply pressure for propane is 11.0 inches water column to 13.0 inches water column. The maximum input rate is 65,000 BTUs.
- FOR OUTDOOR USE ONLY. This unit must be installed at least 60" from center of burner to any combustible walls or material.
- After connecting the gas line, a small amount of air will be in the line. When first lighting the burner, it will take a few seconds for the line to purge itself of the air. Once the purging is complete, the burner will light and operate as indicated in the instruction manual.

PROPANE Operation

- The Oriflamme Fire Table is designed as an "attended appliance". Adults must be present when the unit is operating. Do NOT leave this unit burning when unattended. If this product is left burning unattended it may cause damage or serious injury.
- Alert adults and supervise children who will be in the area of the table and take necessary precautions as with any open flame or hot surfaces.
- Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the Oriflamme Fire Table and to replace any part of the control system and any gas control which has been under water.
- Oriflamme Fire Table should be used ONLY OUTDOORS in a well ventilated area.
- Keep the area around your Oriflamme Fire Table free and clear of from combustible materials, gasoline, lighters, and other flammable vapors and liquids.
- This unit is NOT for use with solid fuel.
- The burner must be replaced by an approved Oriflamme Fire Table burner prior to the appliance being put into operation if it is evident that the burner is damaged.
- When NOT IN USE the control valve MUST be turned off. Rotate right to turn off and rotate left to turn on.

Proper Maintenance

- Inspect valve connections, port and regulator assembly. Look for any damage and remove any debris.
- Inspect the propane fuel supply connection before each use of your Oriflamme Fire Table.
- It is IMPERATIVE the control valve, burner, venture, and circulating air passageways of your Oriflamme Fire Table are kept clean and free of debris.
- Check tank valve features to ensure proper external mating threads.
- If it is evident there is excessive abrasion or wear to the hose or it is cut, the hose must be replaced before use.
- Replacement hose, pressure regulator, and tank must be those specified to your Oriflamme Fire Table.

NATURAL GAS Installation

CAUTION: NATURAL GAS INSTALLATIONS, OTHER MODIFICATIONS AND REPAIRS MUST BE DONE BY A QUALIFIED PROFESSIONAL INSTALLER.

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone.
- Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department

FOR NATURAL GAS: The minimum inlet gas supply pressure for purposes of input adjustment is 7 inches water column and maximum inlet gas supply pressure is 10.5 inches water column. Maximum input rate is 65,000 BTU/Hr.

DO NOT USE IF GAS PRESSURE IS LOWER THAN THE MINIMUM REQUIREMENT OR EXCEEDS THE MAXIMUM.

- Gas piping system must be sized to provide minimum inlet pressure at the maximum flow rate (BTU/hr). Undue pressure loss will occur if the pipe is too small or the run is too long.
- For appliances for fixed fuel piping system and equipped with an appliance gas pressure regulator, the appliance and its individual shutoff valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psi (3.5 kPa).
- The appliance must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psi (3.5 kPa).
- For installations at elevations above 2000 ft. contact your local dealer or gas supplier before installing as input rating should be reduced approximately 4 % for each 1000 ft. above sea level. Refer to the National Fuel Gas Code. Contact the factory for the required orifice.
- The ORIFLAMME FIRE TABLE and its main gas valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of ½ psig. This is accomplished by closing the gas supply line valve, as required by NFPA 54, section 5-54.
- The ORIFLAMME FIRE TABLE must be isolated from the gas supply piping system by closing its equipment shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less that ½ psig.
- GAS SUPPLY PLUMBING REQUIREMENTS Apply only joint compounds that are resistant to all gasses on all male pipe fittings. Make sure to tighten every joint securely. Do not use pipe joint compound to connect flare fittings.
- SAFETY NOTE: An external on/off valve in the gas line is required for safety when your ORIFLAMME FIRE TABLE is not in use. It also provides for convenient maintenance and repair.

ORIFLAMME®

TABLES

uniquely designed fire for an exceptional outdoor experience

DISCOVER THE ORIGINAL DESIGNED FIRE

Crafted with quality and care in the USA, the Oriflamme Fire Table is the premier gas fire table in the marketplace with its height, uniquely designed burners, customization and functionality.

Each Oriflamme Fire Table is designed by the customer who chooses a table top, burner design and fire glass to match their personal style and décor. The finished product becomes a beautiful centerpiece for any outdoor space.

Enjoy the ambiance, warmth and fascination of fire with your own Oriflamme Fire Table!

Designing Fire, Inc.

(800) 445-4559 | www.designingfire.com

Fax: (651) 305-6347 | info@designingfire.com

Manufacturing: Pierre, SD

ASSEMBLY INSTRUCTIONS

TUSCAN TABLE TOP

1. Remove the base from the box.
2. Place a blanket on the ground to protect the surface of the table top.
3. Lay the Tuscan table top face down on the blanket.
4. Take the base and turn it upside down. Line the base up with the 4 pegs and insert the table top into the pegs. (Plastic shavings from the pegs will flake off when frame is inserted into pegs for a tight fit.)
5. Take the table top in one hand and the base in the other and turn it over into an upright position.

ALL OTHER TABLE TOPS

1. Remove the base from the box and the table top from the packaging
2. Place the four plastic plugs into the four corners at the top of the base.
3. With the help of another person, set the table top on the base so it rests on the four plugs.

The propane tank must be filled before continuing assembly.

TABLE ASSEMBLY

1. Place the propane tank diagonally into the frame, set the front bracket into the front pin of the frame. Rotate the propane tank 45º and slide the back bracket of the propane tank into the frame sleeve.
2. Make sure your propane tank is lined up with the control valve.
3. Take the regulator and hook it up to the propane tank, making sure the hose forms a U-shape and the connection is fastened tightly.
4. Take out your burner and notice the venturi tube underneath the burner. Place the burner into the opening of the table and line up the venturi tube with the control valve.
5. Reach your hand through the opening under the control valve and pull the venturi tube over the end cap of the control valve. The tube fits loosely on the end cap for safety and oxygen flow.
6. Open the bags of glass. For design burners, pour the glass into the center for Section A until that is full. Continue to pour glass in Sections B & C until design pattern is complete.
7. To ignite your Oriflamme Fire Table reach underneath and turn the propane tank valve ON. Push the control knob in and turn it to the left to the ON position. Propane will begin flowing into the burner.
8. Take your light stick and light it on top. NEVER light your table from underneath.

Congratulations! Your Oriflamme Fire Table is now assembled and ready for use.

Replacement parts including: Propane Tank, Control Valve, Regulator and Burner are available at your local Oriflamme Fire Table dealer, or contact the manufacturer directly at www.designingfire.com.

ADDITIONAL INSTRUCTIONS

To access your propane tank and place additional accessories into you Oriflamme Fire Table you must remove the burner by using the burner puller.

1. First slide your Venturi tube off the end cap. Find the first burner clip which is located above the control valve.
2. Once you have fastened all three burner clips lift the burner off the table top.
3. Place the ice bucket into the Oriflamme Fire Table, pour your ice into the ice bucket to keep your beverages cool.
4. When your Oriflamme Fire Table is not in use, cover the burner and glass with the included protective lid to keep out debris, children, and pets.

PLEASE REFER TO THE DETAILED INSTRUCTIONAL VIDEO AVAILABLE ON OUR WEBSITE, **www.designingfire.com/assembly**

USER GUIDE

PROBLEM	POSSIBLE CAUSE
Propane tank does not fill	Propane tank was not purged properly
	The OPD float valve on the propane tank has been activated, closing the valve and not allowing the tank to fill.
Smelling propane	Set screw on the side of the propane tank valve assembly is not tight
	Control valve is not completely shut off
	Venturi tube is obstructed
	Venturi tube is not correctly positioned on the control valve
Flame problems: - NO flame - Intermittent flame - Low flame	The tank was not purged properly, it contains of mixture of air and propane. The result is intermittent flame, or flame extinguishes in a short period of time.
	In cooler temperatures, the liquid propane does not convert quickly enough to a gas therefore causing it to “freeze” the outside of the propane tank.
	The regulator was not properly attached to the propane tank.
	Venturi tube is obstructed
	Flame setting too low

CHECKING FOR POSSIBLE LEAKS

1. Remove the table top burner from the base.
2. Make sure the regulator is hooked up to the propane tank with the control valve turned OFF.
3. Turn the propane tank ON. Wait a few seconds a smell for possible leaks where the regulator hose is attached to the control valve or where the regulator is attached to the propane tank.
4. Use soapy water and apply to these areas to verify the leak source.

SOLUTION	NOTES
Take it to an authorized propane station and re-purge the propane tank.	The purging process requires that all air is removed from the propane tank prior to the first fill.
Without the burner, attach the regulator to the propane tank, turn the control valve on for a few seconds to reset the OPD float valve.	The OPD float valve is a safety device which is activated when the propane tank has been filled too quickly.
Use a flat blade screwdriver to tighten the set screw.	
To shut it off, push in the control knob and completely turn it to the right.	The far left position on the control valve is in the lowest setting, not in the OFF position.
Take out the straight portion of the venturi tube and remove the obstruction.	
Slide the venturi tube completely over the control valve assembly. The vents should be in the EAST / WEST position.	The vents are on the end of the straight tube.
Burn off remaining propane and re-purge the tank	The purging process requires that ALL air is removed from the propane tank prior to the first fill to ensure maximum efficiency.
Turn down the flame slightly to where the control valve is not wide open.	
Disconnect the regulator and reconnect it properly to the propane tank.	
Take out the straight portion of the venturi tube and remove the obstruction.	
Turn the control knob to the right for a higher flame setting.	

TABLE TOP MAINTENANCE

GRANITE TABLE MAINTENANCE

Granite is a dense, coarse-grained stone and one of the hardest materials on earth. Its luster, hardness, colors and variations are all indications of the stone's mineral composition and origin. Most have pits or fissures that are inherent to the stone and are part of its rich natural texture and beauty.

GENERAL FACTS ABOUT GRANITE:

- The granite table top is hard and durable and is very resistant to scratching when properly sealed and maintained.
- The granite table top is completely heat resistant and can withstand temperatures upwards of 1800 degrees Fahrenheit.
- To prevent staining and scratches, use a granite sealer as per the MFG recommendations. Be sure to wipe up spills immediately.
  When the granite is wet, it may appear darker.
- The pits and fissures are random pronounced markings common to some stones and cannot be removed during fabrication.

MAINTAINING THE GRANITE:

- Use a mild soap and water or a professional natural stone cleaner for daily use.
- Do not use abrasive cleaners.
- To ensure the beauty of your granite table top, it should be sealed twice a year.

TUSCAN STONE MAINTENANCE

The Tuscan stone top achieves the appearance of real stone with the use of Century Stone natural iron oxides and quartz concrete overlay. Each table is hand stained using iron oxides. These oxides are water based colorants, not solid colors like paints. The oxides mixed with water and applied by hand give the table a "natural" look.

Colors will vary from table to table because the stain is translucent and texture varies because each table is hand troweled. Please be aware that the "tone" of the color will be the same, but the exact shade may vary. Different texture surfaces may also affect table colors. We cannot guarantee a match to any existing table or sample. Our goal is to "complement or blend" the chosen color or sample and assure you the best quality table.

- Do not place anything with a "rubber compound" on the table. This can permanently mark the surface.
- Place a tray under all potted plants. Oxides and minerals in pots and soil can discolor the table top.
- To ensure complete protection for your Tuscan table top, we recommend the full cover available for purchase.

MAINTAINING THE TUSCAN STONE:

- Wipe down table top regularly with a damp cloth.
- Wipe up spills immediately.
- Use "Simple Green®" or a natural citrus cleaner and sponge for difficult areas.
- Use "Dawn®" dishwashing liquid and water for grease or oil spots.
- Use "Mr. Clean Magic Eraser®" for small, hard to clean areas.

MARBLE STONE “VENETIAN”

GENERAL FACTS ABOUT MARBLE STONE:

- Marble is a natural stone formed over millions of years
- The crystalline properties of the minerals give the marble is distinctive colors, veining and graining.
- The surface has been filled, polished and sealed creating a uniform, general non-porous surface.
- Veining, hairline cracks and color variations are part of the intrinsic beauty of marble

MAINTAINING THE MARBLE STONE:

- Protect marble surface from scratching, staining and etching.
- Keep surface free of debris and sharp objects
- Wipe up spills immediately
- Avoid contact with chemicals (particularly acid based materials)
- Clean with pH neutral products
- After a period of use, apply a penetrating sealer to prevent contaminants from being absorbed into the stone.
- Renew the surface on polished marble by buffing with special stone polish.
- Do not use marble polish on matte finish marble.

MOSAIC STONE “SANTA FE”

GENERAL FACTS ABOUT NATURAL SLATE:

- Slate is a natural stone and no two pieces are ever alike
- Consists of thin layers of stone and as the layers of slate are separated, unique patterns and colors emerge
- Natural unevenness and variation in authentic slate which adds to its diversity
- Highly resistant to abrasion and cracking
- No rusting because of its high purity
- Density of slate makes it ideal for outdoors
- Harder than marble

MAINTAINING THE NATURAL SLATE:

- Resistant to stains, will not fade or discolor in sunlight.
- Slate top is sealed with a stone sealer and this sealer should be re-applied each year.
- Can be cleaned with water or mild soapy water.
- Do not use vinegar, abrasive cleaners, furniture polish or cleaners that contain acid.
- Should be stored in a dry location during the off season and not resting on its side

---

MOSAIC STONE “SAHARA”

GENERAL FACTS ABOUT TRAVERTINE:

- Travertine is a unique natural stone that is rich with historical significance and has been quarried for over two thousand years and is a product of the earth’s water and carbon cycles.
- It is formed by minerals dissolving in ground water and then being deposited on the earth’s surface by rivers, natural springs, or geysers.
- The two minerals that make up 99% of travertine are calcite and gypsum which are colorless.
- Beautiful tones come from traces of yellow sulfur, brown iron compounds, and organic pigments.
- The texture of travertine is partly the result of gas bubbles trapped between layers of stone.
- Each piece has its own distinct character, adding beauty and unique style to any décor.

MAINTAINING THE TRAVERTINE:

- NEVER rest or stand this stone on its side!
- Since this stone is sealed, it requires only regular wiping with water or occasionally with mild soapy water.
- Do not use vinegar, cleaners that contain acid, abrasive cleaners, or furniture polish.
- Do not high-pressure wash this stone top.
- If a stain does occur, it can be easily removed with fine (0) steel wool or finer grit sand paper. If this step is required at any point the surface area affected needs to be treated with a stone sealer for further protection.
- Use a stone sealer once per year.
- For long-term maintenance, store the top in a dry location during the off season and DO NOT rest it on its side.

HAMMERED COPPER

GENERAL FACTS ABOUT HAMMERED COPPER:

- Copper is mined and extruded into copper sheets
- Sheets are shaped and hammered with a dark acid-etched finish applied
- Tops can be formed onto outdoor substrates
- 18 gauge copper is used
- Special finish is applied to maintain patina

MAINTAINING THE HAMMERED COPPER:

- Top requires regular wiping with water or mild soapy water with soft cloth
- Vinegar, cleaners that contain acid abrasive cleaners or furniture polish should NOT be used

---

CANYON STONE AND SANDSTONE

GENERAL FACTS ABOUT GFRC

- GFRC is glass fiber reinforced concrete
- Uses special glass fibers rather than steel for reinforcement
- Super hybrid with special additives
- Lightweight--up to 75% lighter than pure concrete or stone
- Strong--does not crack easily with higher tensile strength than steel
- Eco friendly--uses natural raw materials with much lower environmental impact
- Does not give off toxins or pollutants when produced

MAINTAINING THE GFRC:

- Table tops are sealed
- Periodic applications of low or flat sheen wax will protect surface
- Use household wax, Pledge or clear coat car wax
- Clean top with soapy water and dry thoroughly before applying wax

WARRANTY

TABLE TOP

Designing Fire, Inc. offers a (2) year, (1) year COMMERCIAL warranty on table tops valid only with proper maintenance from date of delivery. This limited warranty covers craftsmanship and structural components of the table top. Designing Fire, Inc., at manufacturer's option, will repair or replace any table top found to be defective during this warranty period. Warranty is void if any of the following occurs: 1) Incorrect installation by retailer or customer 2) damage caused by accidents, 3) misuse, 4) alterations made by anyone other than Designing Fire Inc. manufacturers.

Note: This warranty does not apply to the use of another manufacturer's table top, nor does it apply to the incorrect installation of the table top onto the base, by the retail store or customer. This warranty does not apply to any damage caused by shipping, accidents, fading, staining, natural weathering, misuse, alterations or repairs.

COMPONENTS

Designing Fire, Inc. offers a (3) year, (1) year COMMERCIAL, functional warranty only with proper maintenance from date of delivery for all working components of the table such as the burner, propane tank, control valve and regulator. Designing Fire, Inc. will, at manufacturer's option, repair or replace any Designing Fire, Inc. component that has failed functionally during normal use and proper maintenance.

FRAME

Designing Fire, Inc. offers a LIFETIME, (5) year COMMERCIAL, structural warranty only with proper maintenance from date of delivery. Designing Fire Inc. will, at manufacturer's option, repair or replace any Designing Fire, Inc. frame that has failed structurally during normal use and proper maintenance.

FINISH

Powder Coat: Designing Fire, Inc. offers a (7) year, (1) year COMMERCIAL, warranty against blistering or peeling of the frame finish under normal use and proper maintenance. Designing Fire, Inc., at manufacturer's option, will refinish or replace your powder coated materials if either of the above occurs within a (7) year period from the date of purchase. Occasional rust seepage from crevices and hidden unfinished surfaces inherent in some ornate designs is considered not a finish failure. Extra care and maintenance is required in coastal areas.

NOT COVERED UNDER WARRANTY

- This warranty does not apply to any damage caused by shipping, accidents, fading, staining natural weathering, misuse, alterations or repairs. No other person is authorized to assume liability on behalf of Designing Fire, Inc., and in no event shall Designing Fire, Inc. be liable for contributory or subsequent damage related to merchandise purchased from Designing Fire, Inc.
- Any failure caused by unreasonable use or abuse
- Rust seepage or bleeding from cracks or crevices
- Rust and/or oxidation of frame resulting from exposed metals that have been scratched, chipped or not properly maintained by the guidelines listed in the care instructions
- Normal fading of the Oriflamme Fire Table
- Customer's own material choices
- Accidental damage or element damage such as fire, wind, rain, or sun
- Permanent stains caused by lotions, oils, or other substances
- Discoloring of the fire glass due to unreasonable use
- Furniture used for commercial or institutional use

MAINTENANCE INSTRUCTIONS

- Oriflamme Fire Table should be inspected before initial use, and regularly inspected and cleaned.
- Oriflamme Fire Table should be kept clean and free of dirt build up. Clean with mild soap and water. Wipe spills quickly to avoid surface staining, scrubbing with soft sponge or rag. See complete details for table top maintenance in table top care instructions page.
- Never leave table standing in water.
- Cover or store your table when not in use for extended periods of time.
- Tampering is dangerous and will void all warranties. Any component that is found to be faulty must be replaced with an approved component.
- Examine the burner and venturi tube to make sure that there is no lint or dirt in these areas.

TABLE RETURN GUIDELINES

PRIOR AUTHORIZATION from the manufacturing or manufacturers' representative is required. You must be the original purchaser and be able to provide proof of purchase when you make a claim. To submit a warranty claim, contact our warranty department at (800) 445-4559, via fax, (651) 305-6347 and/or via email at admin@designingfire.com; or you may contact your local dealer.

If the complaint is covered by warranty, Designing Fire, Inc. will arrange for freight pick-up and pay the surface freight to and from manufacturing. The consumer is responsible for freight charges to and from the manufacturing if beyond the timeframe stated above. Return of the Oriflamme Fire Table must be packaged for freight pick up. Oriflamme Fire Tables must have been used only for residential use as defined in the original purchase order.

For more product information, visit our website:
www.designingfire.com

©2013 Designing Fire, Inc. All rights reserved.

Pour les informations de plus de produit, visiter notre site
www.designingfire.com

©2013 Designing Fire,Inc. Tous droits réservés.

Vendre au détail

le SOMMET DE TABLE de Garantie Conçoit le Feu, Inc. offre un (1) la garantie d'an sur la Pierre et Granit toscane dépasse valide seulement avec l'entretien correct de la date de livraison. Cette garantie limitée couvre l'habileté technique et les composants structurels du sommet de table. Concevoir le Feu, Inc., à l'option du fabricant, réparera ou remplacera n'importe quel sommet de table a trouvé pour être défectueux pendant cette période de garantie. La garantie est vide si n'importe lequel du suivre arrive :

1) l'installation Inexacte par le détaillant ou le client

2) les dommages causés par les accidents,

3) l'usage impropre,

4) les changements faits par n'importe qui autrement que Concevoir de Feu Inc. les fabricants.

Note : Cette garantie ne s'applique pas à l'usage d'un autre sommet de table du fabricant, ni le fait s'applique à l'installation inexacte du sommet de table sur la base, par le magasin ou le client. Cette garantie ne s'applique pas aux dommages causés par l'expédition, les accidents, palîr, tacher, mûrir naturel, l'usage impropre, les changements ou les réparations.

CADRE/COMPOSANTS Concevant le Feu, Inc. offre un (2) l'an garantie structurelle seulement avec l'entretien correct de la date de livraison. Concevoir le Feu Inc. la volonté, à l'option du fabricant, réparer ou remplacer le Feu Concevant, Inc. le cadre qui a échoué structurelment pendant l'usage normal et l'entretien correct.

FINIR du Manteau de Poudre : Concevoir le Feu, Inc. offre un (2) la garantie d'an contre peler ou peler de la fin de cadre sous l'usage normal et l'entretien correct. Concevoir le Feu, Inc., à l'option du fabricant, refinira ou remplacera votre poudre vos matériels revêtus si ou de l'au-dessus arrive dans un (2) la période d'an de la date d'achat. L'infiltration occasionnelle de rouille des fissures et des surfaces inachevées cachées inhérentes dans quelques conceptions ornées est considéré une fonction de soin et entretien et n'est pas considéré un échec de fin.

PAS COUVERT SOUS GARANTIE échec causé par l'usage déraisonnable ou l'infiltration de Rouille d'abus ou saignant des fissures ou des fissures Rouille l'oxydation de et/ou de cadre qui résulte des métaux exposés qui a été gratté, écaillé ou pas convenablement maintenu par les indications énumérées dans les instructions de soin palîr Normal du Client de Table de Feu d'Oriflamme les propres dommages accidentels de choix ou les dommages d'élément matériels comme le feu, le vent, la pluie, ou le soleil taches Permanentes Causé par les lotions, les pétroles, ou les autres substances Décolorant du verre de feu en raison d'INDICATIONS DE RETOUR DE TABLE d'usage déraisonnables

AUTORISATION PREALABLE du représentant de fabrication ou fabricants est exigée. Vous devez être l'acheteur original et pouvez fournir la preuve d'achat quand vous faites une réclamation. Pour soumettre une réclamation de garantie, contacter notre département de garantie à (800) 445-4559, via la télécopie, (651) 305-6347 et/ou par courrier électronique à admin@designingfire.com ; ou vous pouvez contacter votre négociant local. Si la plainte est couverte par la garantie, Concevant le Feu, Inc. arrangera pour le camion de fret et paie le fret de surface à et de la fabrication. Le consommateur est responsable des charges de fret à et de la fabrication si au-delà du calendrier affirmé au-dessus. Le retour de la Table de Feu d'Oriflamme doit être emballé pour le fret prend. Les Tables de Feu d'Oriflamme doivent avoir été seulement utilisées pour l'usage résidentiel comme défini dans la facture d'achat originale.

Entretien de granit de Table

quel est de granit ?
Le granit est une pierre dense et à gros grain et un des matériels les plus durs sur la terre. Son lustre, sa dureté, colore de le et les variations sont toutes les indications de la composition de la pierre minérale et l'origine. Les plus a des fosses ou des fissures qui est inhérentes à la pierre et font partie de sa texture et sa beauté naturelles riches.

Comment les durables sont de granit ?
La Table de Feu d'Oriflamme le sommet de table de granit est extrêmement durable. La seule pierre plus dure que granit est le diamant. La surface peut-elle être grattée ? La Table de Feu d'Oriflamme le sommet de table de granit peut être seulement gratté par un autre morceau de granit ou par un diamant.

Le granit peut-il être brûlé ?
La Table de Feu d'Oriflamme le sommet de table de granit est complètement chauffe résistant et peut résister à des températures plus de 1800 degrés Fahrenheit.

Le granit peut-il ajourner le sommet est taché ?
Pour empêcher tacher, utiliser un sealer de granit régulièrement. Etre sûr d'essuyer des renversements tout de suite. Quand le granit est mouillé, il peut apparaître plus sombre en couleur.

Les fosses ou les fissures de la pierre peuvent-ils être enlevés ?
Les fosses et les fissures sont des marques prononcées faites au hasard communes à quelques pierres et ne peuvent pas être enlevés pendant la fabrication.

MAINTENIR LA TABLE DE FEU D'ORIFLAMME LE SOMMET DE TABLE DE GRANIT :

- Utiliser un savon doux et une eau ou un professionnel un nettoyeur en pierre naturel pour l'usage quotidien
- n'utilise pas des nettoyeurs abrasifs
- **garantir la beauté de votre sommet de table de granit, il devrait être scellé tous les ans.**

Entretien toscan de Table

Le sommet en pierre toscan atteint l'apparence de vraie pierre avec l'usage de CenturyStone les oxydes en fer naturels et le dessin superposé concret à quartz. Chaque table est la main a taché utilisant des oxydes en fer. Ces oxydes sont de l'eau les colorants basés, les couleurs pas solides comme les peintures. Les oxydes mélangés avec l'eau et appliqué donne à la main un regard « naturel » à la table. Les couleurs varieront de la table pour ajourner parce que la tache est translucide et la texture varie parce que chaque table est troweled de main. S'il vous plaît être conscient que le « ton » de la couleur sera le même, mais l'ombre exacte peut varier. Les surfaces différentes de texture peuvent affecter aussi les couleurs de table. Nous ne pouvons pas garantir un match à la table ou l'échantillon actuelle. Notre objectif est « compléter ou mélanger » la couleur ou l'échantillon choisi et vous assure la meilleure table de qualité.

INSTRUCTIONS toscanes DE NETTOYAGE DE PIERRE :

- La Lingette en bas le sommet de table régulièrement avec un tissu humide.
- Essuyer des renversements tout de suite.
- L'Usage « Simple Vert® » ou un nettoyeur d'agrume naturel et éponge pour les secteurs difficiles.
- L'Usage « Dawn® » le liquide de vaisselle et l'eau pour la graisse ou le pétrole aperçoivent.
- L'Usage « M.e Gomme Magique Propre® » pour petit, fort nettoyer des secteurs.

NOTES SUPPLEMENTAIRES :

- Ne pas placer n'importe quoi avec un « le composé de caoutchouc » sur la table. Ceci peut marquer d'une façon permanente la surface.
- Placer un plateau sous toutes les plantes en pot. Les oxydes et les minéraux dans les pots et le sol peuvent décolorer le sommet de table.
- Garantir la protection complète pour votre sommet de table toscan, nous recommandons la couverture pleine nous avons disponible pour l'achat.

Le Réservoir de propane Dépannant

Ce Guide de dépannage est pour les gens de métier qui remplissent votre réservoir de propane.

PROBLEME : Le cylindre ne remplira pas ou ne prendra pas du gaz. Ceci arrive d'ordinaire sur le remplit premièrement ou si le cylindre est complètement vide.

Que cause ceci d'arriver ?
L'OPD est le flotteur fonctionné et le fond du cylindre est en forme de plat. Si un haut débit de liquide est forcé dans le cylindre vide, le liquide éclaboussera quelquefois sur et conduit le flotteur jusqu'à la position fermée. Quand l'épingle appartient au replis de la came, il empêche le flux de propane.

Comment ce problème peut-il être résolu ?
1. Débrancher le remplir le tuyau.
2. Insérer l'adaptateur approprié dans la sortie de la soupape de service.
3. Ouvrir la roue de main et relâcher la pression de l'OPD pour permettre lui remettre à l'état initial.

Pour empêcher la fermeture prématurée de la soupape d'OPD :
1. La soupape de service sur le cylindre devrait être fermée.
2. Le remplir la fin de tuyau a une soupape intérimaire rapide, la soupape intérimaire rapide sera ouverte et la soupape de service devrait être lentement ouverte pour empêcher la hâte soudaine de liquide dans le cylindre.
3. Après que quelque liquide remplit l'a servi le fond et la pression est égalisée, le flux dans le cylindre peut être augmenté.

Note : Les vidéos de dépannage sont disponibles sur notre site Web, www.designingfire.com/customercare.

LES INFORMATIONS SUPPLEMENTAIRES DE RESERVOIR DE PROPANE
- Le réservoir de propane est fabriqué par le Réservoir de Manchester.
- La capacité d'eau du réservoir est 26,1 livres.
- Les Autres réservoirs de propane ne peuvent pas être acceptables pour l'usage avec la Table de Feu d'Oriflamme.
- Le réservoir de propane doit être construit et doit être conformément marqué aux Spécifications de Ministère des Transports américaines pour Cylindres de LP-GAZ, ou la Norme pour les Cylindres, les Sphères et Tubes pour Transport d'Articles et la Commission Dangereux, CAN/CSA-B339 comme applicable ; et fourni avec un trop remplir l'appareil d'empêchement énuméré ; et fourni avec un appareil de connexion de cylindre compatible avec la connexion pour l'appareil.
- Voir Assemblée Instructions à la page 6-7 pour informaton sur comment connecter/débranche la provision de gaz ou le contrôle pour les fuites. La photo au dessous de montre l'assemblée complétée.

6. Ouvrir les sacs de verre. Pour les brûleurs de conception, verser le verre dans le centre pour Sectionne UN jusqu'à ce que cela est plein. Continuer à verser le verre Sectionne B & C jusqu'à ce que le modèle de conception est complet.
7. Pour allumer votre portée de Table de Feu d'Oriflamme en dessous, pousser le bouton de contrôle et le tourne en à la gauche au SUR la position. Le propane commencera couler dans le brûleur.
8. Prendre votre bâton léger et l'allume sur le sommet. **Ne JAMAIS allumer votre table d'en dessous.**

Félicitations ! Votre Table de Feu d'Oriflamme est maintenant assemblée et prêt pour l'usage.

Les pièces de rechange y compris : Le Réservoir de propane, Soupape de Contrôle, le Régulateur et Brûleur sont disponibles à votre négociant de Table de Feu d'Oriflamme local, ou contacter le fabricant directement à www.designingfire.com.

LES INSTRUCTIONS SUPPLEMENTAIRES

pour accéder à votre réservoir de propane et placent des accessoires supplémentaires dans vous le Feu d'Oriflamme Ajourne doit vous enlever le brûleur en utilisant l'extracteur de brûleur.

1. La première chute votre tube de Venturi de l'embout protecteur. Trouver le premier trombone de brûleur qui est au-dessus localisé de la soupape de contrôle.
2. Une fois vous avez attaché tous les trois trombones de brûleur soulèvent le brûleur du sommet de table.
3. Placer le seau à glace dans la Table de Feu d'Oriflamme, verser votre glace dans le seau à glace pour garder vos boissons refroidissent.
4. Quand votre Table de Feu d'Oriflamme n'est pas dans l'usage, couvrir le brûleur et le verre avec le couvercle protectif inclus pour empêcher d'entrer du débris, les enfants, et les animaux favoris.

VERIFIER POUR LES FUITES POSSIBLES

1. Enlever la table le premier brûleur de la base.
2. Assurer que le régulateur est fait un duplex entre le réservoir de propane avec la soupape de contrôle a éteint.
3. Allumer le réservoir de propane. Attendre quelques-uns appuient une odeur pour les fuites possibles où le tuyau régulateur est attaché à la soupape de contrôle ou où le régulateur est attaché au réservoir de propane.
4. Utiliser l'eau savonneuse et s'applique à ces secteurs pour vérifier la source de fuite.

Les Instructions d'assemblée se

REFERENT S'IL VOUS PLAIT AU DISPONIBLE DE VIDEO DE D'INSTRUCTION DETAILLE SUR NOTRE site Web, www.designingfire.com/assembly

LA TABLE toscane DEPASSE

1. Enlever la base de la boîte.
2. Placer une couverture par terre pour protéger la surface du sommet de table.
3. Poser la table le toscane premier visage en bas sur la couverture.
4. Prendre la base et le met à l'envers. Revêtir la base en haut avec les 4 chevilles et insérer le sommet de table dans les chevilles. (Les rasages en plastique des chevilles émietteront loin quand le cadre est inséré dans les chevilles pour une crise tendue).
5. Prendre le sommet de table dans une main et la base dans l'autre et le tourne sur dans une position verticale.

LA TABLE DE GRANIT DEPASSE

1. Enlever la base de la boîte et le sommet de table de granit de l'emballage
2. Placer le quatre en plastique connecte aux quatre coins en haut de la base.
3. A l'aide d'une autre personne, régler le sommet de table de granit

sur la base s'il se repose sur les quatre bouchons. Le réservoir de propane doit être rempli avant de continuer l'assemblée. Voir des instructions de propane à la page 8.

AJOURNER ASSEMBLEE

1. Prendre le réservoir de propane et l'a réglé dans la table, se reposant sur le crochet de la base.
2. Assurer que votre réservoir de propane est aligné avec la soupape de contrôle.
3. Prendre le régulateur et l'accroche jusqu'à le réservoir de propane, assurer que le tuyau forme une forme d'U et la connexion est solidement attachée.
4. Sortir votre brûleur et remarquer le tube de venturi au-dessous du brûleur. Placer le brûleur dans l'ouverture de la table et la ligne sur le tube de venturi avec la soupape de contrôle.
5. Atteindre votre main par l'ouverture sous la soupape de contrôle et tirer le tube de venturi sur l'embout protecteur de la soupape de contrôle. **Le tube ajuste lâchement sur l'embout protecteur pour la sécurité et l'oxygène coule.**

ORIFLAMME®
TABLES

"a conçu uniquement le feu pour une expérience extérieure exceptionnelle"

LA DECLARATION DE MISSION

Conçoit le Feu, Inc. est commis à fournir une table de feu uniquement conçue qui améliorera l'expérience et l'environnement extérieure sociale de ses propriétaires. Maintenir une norme d'excellence dans le développement du produits nouveaux, garantissant l'intégrité, et livrer un niveau supérieur de service clientèle est des clés au succès de concevoir le Feu, Inc. et son réseau de consommateur entier.

CE QUE FAIT LE FEU D'ORIFLAMME AJOURNE EXTRAORDINAIRE ?

La Table de Feu d'Oriflamme est uniquement le vôtre parce que vous le personnalisez avec vos choix de dessus de table, de conception de brûleur et de couleurs de verre de feu. Facile à monter, léger, portatif, et à la hauteur de table basse, perfectionner pour relâcher ou les relations. En plus de fournir de chaleur sans la fumée, les cendres ou les braises ardentes, la Table de Feu d'Oriflamme améliore votre espace extérieur avec l'ambiance spéciale de feu conçu. Aucune autre table de feu dans le marché d'aujourd'hui égale la Table de Feu d'Oriflamme dans la qualité, le caractère fonctionnel ou l'élégance. La Table de Feu d'Oriflamme est véritablement une oeuvre d'art.

Est Commencé les Instructions

de Sécurité de Guide 2-3

Introduction 5

Assemblée 6-7

Informations de Réservoir de Propane 8

Entretien toscan de Table 9

Entretien de granit de Table 10

Informations de Garantie 11

L'Installation de PROPANE

- A Lu les instructions ont fourni à fond avant d'installer et fonctionner votre Table de Feu d'Oriflamme.
- L'installation Déplacée, l'ajustement, le changement, le service, ou l'entretien peut causer les dommages de propriété, la blessure personnelle, et ou la mort.
- LE CODE ET FOURNIT CONDITIONS : La Table de Feu d'Oriflamme doit être conformément installée aux codes et les ordonnances locales, ou en l'absence de codes locaux, avec le Code de Gaz de Carburant National, ANSI Z223.1/NFPA 54 ou le Code de Gaz de Carburant International.
- La pression maximum de provision de gaz d'arrivée pour le propane est 11,0 colonne d'eau de pouces à 13,0 pouces arrose la colonne. Le taux d'entrée maximum est 65.000 unités calorifiques.
- POUR UTILISATION A L'EXTERIEUR SEULEMENT. Cette unité doit être installée au moins 60" du centre de brûleur aux murs ou de matériel combustible.
- Après avoir connecté la ligne de gaz, une petite quantité d'air sera dans la ligne. En allumant premièrement le brûleur, il prendra quelques secondes pour la ligne pour lui-même se purger de l'air. Une fois le purger est complet, le brûleur allumera et fonctionnera comme indiqué dans le manuel d'utilisation.

L'Opération de PROPANE

- La Table de Feu d'Oriflamme est conçue comme un « a assisté l'appareil ». Les adultes doivent être présents quand l'unité fonctionne. Ne pas partir cette unité qui brûle quand indépendant. Si ce produit est parti brûlant indépendant il peut causer des dommages ou la blessure sérieuse.
- Les adultes Vigilants et surveille des enfants qui seront dans le secteur de la table et prend des précautions nécessaires comme avec la flamme ouverte ou les surfaces chaudes.
- Ne pas utiliser cet appareil si la partie a été sous l'eau. Tout de suite appeler un technicien d'entretien qualifié pour inspecter la Table de Feu d'Oriflamme et remplacer n'importe quelle partie du système de contrôle et n'importe quel gaz contrôle qui a été sous l'eau.
- La Table de Feu d'Oriflamme devrait être utilisée SEULEMENT DEHORS dans un secteur bien ventilé.
- Garder le secteur autour de votre Table de Feu d'Oriflamme libère et éclaircit de des matériaux inflammables, l'essence, les briquets, et les autres vapeurs et les liquides inflammables.
- Cette unité n'est pas pour l'usage avec le combustible solide.
- Le brûleur doit être remplacé par un brûleur de Table de Feu d'Oriflamme approuvé avant l'appareil est mis dans l'opération s'il est evident que le brûleur est endommagé.
- Quand PAS DANS UTILISER la soupape de contrôle doit être éteinte. Tourner juste pour éteindre et tourner gauche pour allumer.

L'Entretien correct

- Inspecte les connexions de soupape, le port et l'assemblée régulatrice. Chercher n'importe quels dommages et enlever n'importe quel débris.
- Inspecter la connexion de provision de carburant de propane avant chaque usage de votre Table de Feu d'Oriflamme. • C'est IMPERATIF la soupape de contrôle, le brûleur, l'entreprise, et les passages d'air de circulation de votre Table de Feu d'Oriflamme est gardé propre et libre de débris.
- Les caractéristiques de soupape de réservoir de Contrôle pour garantir accoupler les fils externes corrects.
- Si c'est évident qu'il y a le frottement ou l'usure excessif au tuyau ou il est coupé, le tuyau doit être remplacé avant l'usage. • Le tuyau de rechange, le régulateur de pression, et le réservoir doit être ces spécifié à votre Table de Feu d'Oriflamme.

LA PRUDENCE NATURELLE d'Installation de GAZ : INSTALLATIONS NATURELLES DE GAZ, LES AUTRES MODIFICATIONS ET LES AUTRES REPARATIONS DOIVENT ETRE FAITS PAR UN PROGRAMME D'INSTALLATION PROFESSIONNEL QUALIFIE.

CE QUE FAIRE SI VOUS SENTEZ DU GAZ :

- Ne pas essayer d'allumer de l'appareil.
- Ne pas toucher du commutateur électrique ; ne pas utiliser du téléphone dans votre bâtiment.
- Tout de suite appeler votre fournisseur de gaz d'un téléphone du voisin.
- Suivre les instructions du fournisseur de gaz.
- Si vous ne pouvez pas atteindre votre fournisseur de gaz, appelez les pompiers

POUR LE GAZ DE NATUREL : La pression minimum de provision de gaz d'arrivée pour les buts d'ajustement d'entrée est 7 colonne d'eau de pouces et la pression de provision de gaz d'arrivée maximum est 10,5 colonne d'eau de pouces. Le taux d'entrée maximum est 65.000 unité calorifique/Hr.

LE PAS UTILISE SI GAZE DE LA PRESSION EST PLUS BAS QUE LA CONDITION MINIMUM OU DEPASSE LE MAXIMUM.

- Gazer battant le système doit être calibré pour fournir la pression d'arrivée minimum au débit maximum (unité calorifique/hr). La perte injustifiée de pression arrivera si le tuyau est trop petit ou la course est trop longtemps.
- Pour les appareils pour le carburant fixe qui bat le système et équipé avec un régulateur de pression de gaz d'appareil, l'appareil et sa soupape d'arrête individuelle doit être débranché de la provision de gaz qui bat le système pendant n'importe quel essai de pression de ce système aux pressions de test dépassant 1/2 livres par pouce carré (3,5 kPa).
- L'appareil doit être isolé de la provision de gaz qui bat le système en fermant sa soupape d'arrête, manuelle et individuelle pendant n'importe quel essai de pression de la provision de gaz qui bat le système aux pressions de test égale à ou moins que 1/2 livres par pouce carré (3,5 kPa).
- Pour les installations aux élévations au-dessus de 2000 pied contacte votre négociant local ou votre fournisseur de gaz avant d'installer comme le classement de données devrait être approximativement réduit 4 % pour chacun 1000 pied au-dessus du niveau de la mer. Se référer au Code National de Gaz de Carburant. Contacter l'usine pour l'orifice exigé. • La TABLE DE FEU D'ORIFLAMME et sa soupape de gaz principale doivent être débranchés de la provision de gaz qui bat le système pendant n'importe quel essai de pression de ce système aux pressions de test dépassant ½ psig. Ceci est accompli en fermant la soupape de ligne de provision de gaz, comme exigé par NFPA 54, section 5-54.
- La TABLE DE FEU D'ORIFLAMME doit être isolée de la provision de gaz qui bat le système en fermant sa soupape de coupure d'équipement pendant n'importe quel essai de pression de la provision de gaz qui bat le système aux pressions de test égale à ou moins qui ½ psig.
- LA PROVISION DE GAZ SONDANT CONDITIONS Appliquent composés seulement des communs qui sont résistants à tout le gasses sur toutes les installations de tuyau mâles. Assurer se resserrer chaque joint assurément. Ne pas utiliser le tuyau composé commun pour connecter les installations de fusée éclairante.
- NOTE DE SECURITE : Une soupape externe de marche/arrêt dans la ligne de gaz est exigée pour la sécurité quand votre TABLE DE FEU D'ORIFLAMME n'est pas dans l'usage. Il pourvoit aussi à l'entretien et à la réparation commodes.

⚠ AVERTISSEMENT

DANGER MONOXIDE DE CARBONE

Cet appareil peut produire monoxyde de carbone qui n'a pas d'odeur.

L'utilisation il dans un espace enclos peut vous tuer.

Ne jamais utiliser cet appareil dans un espace enclos comme un campeur, une tente, une voiture ou une maison.

⚠ AVERTISSEMENT

L'ÉCHEC POUR SUIVRE À CES INSTRUCTIONS PEUT AVOIR POUR RÉSULTAT UNE EXPLOSION OU UN FEU QUI PEUT CAUSER LES DOMMAGES DE PROPRIÉTÉ, LA BLESSURE OU LA MORT

- **Les enfants et les adultes devraient être alertés aux dangers d'haute température de la surface et devraient rester loin éviter des brûlures ou de l'allumage de vêtement.**
- **Les jeunes enfants devraient être soigneusement surveillés quand ils sont dans le secteur de la Oriflamme Fire Table.**
- **Le vêtement ou les autres matériels inflammables ne devraient pas être pendus de l'appareil, ou placé sur ou près de la Oriflamme Fire Table.**
- **N'importe quel garde ou l'autre appareil protectif a enlevé pour entretenir l'appareil doit être remplacé avant fonctionner la Oriflamme Fire Table.**
- **L'installation et la réparation devraient être faites par une personne de service qualifiée. La Table de Feu d'Oriflamme devrait être inspectée avant l'usage et au moins annuellement par une personne de service qualifiée. Le nettoyage plus fréquent pourrait être comme exigé nécessaire. C'est impératif que le compartiment de contrôle, les brûleurs et les passages d'air de circulation de la Table de Feu d'Oriflamme est gardé propre.**

⚠ AVERTISSEMENT

L'installation de Déplacé d'AVERTISSEMENT, l'ajustement, le changement, le service ou l'entretien peuvent causer les dommages de blessure ou propriété. Lire l'installation, fonctionnant de le et les instructions à fond avant d'installer ou entretenir cet équipement.

⚠ LE DANGER

Si vous sentez du gaz:

1. **Eteindre le gaz à l'appareil.**
2. **Eteindre la flamme ouverte.**
3. **Si l'odeur continue, évite l'appareil et appelle tout de suite votre fournisseur de gaz ou les pompiers.**

⚠ AVERTISSEMENT

L'AVERTISSEMENT n'emmagasine pas ou utilise de l'essence ou les autres vapeurs et les liquides inflammables à proximité de ceci ou aucun autre appareil. Un LP-CYLINDRE n'a pas connecté pour l'usage ne sera pas emmagasiné à proximité de ceci ou aucun autre appareil.

⚠ WARNING
POUR UTILISATION A L'EXTERIEUR SEULEMENT

ORIFLAMME®
TABLES

Est Commencé le Guide

Les Instructions d'assemblée
Entretien d'Informations
de Garantie Dépannant

DESIGNINGFIRE
MANUFACTURER OF THE ORIFLAMME TABLE

(800) 445-4559 | www.designingfire.com

#253915-2528907

Programmes d'installation : S'il vous plaît partir le manuel d'utilisation avec le consommateur pour la référence future.

©2013 Designing Fire, Inc. Tous droits réservés.